HIGOLD

G 2.0 series double spring and soft -close ball bearing slide

Installation manual

G 2.0 series double spring and soft-close ball bearing slide

All series product size introduce

Installation instruction

Installation dimension

Installation Requirements for Compatible Drawers:

1. Ensure an installation clearance of 21mm (+0.5,-0.0) is maintained at both sides.
2. The mounting holes for the inner rail shall be positioned at a height of 23mm (+0.0,-0.2) from the drawer base plate.

01

Installation tool

Measuring tape rulers, Ruler, Pencils, Electric screwdrivers.

02

How to choose the length of ball bearing slide

Measure cabinet depth as 550mm and drawer length as 462mm(Recommends). Installation is using 450mm Soft-close ball bearing slide.

03

Preparations

1 Pair 450mm ball bearing slide
14 pcs of ST3.5*16 flat head screws

Press the release fork the the remove the inner slide.

04

Assemble of the inner slide

The inner rail mounting height is specified as 23.0+0.0/-0.2mm from the drawer bottom plate. For the installation, set the rail mounting height at 23.0mm. Mark it as the parallel to the bottom edge at 23mm from the drawer base.

Use a steel ruler to measure and mark the distances on the parallel line.

Secure the inner rails to the pilot holes at the marked positions using self-tapping screws, with at least three screws per inner slide.

Similarly, install the inner rail on the other side of the drawer. The inner rail assembly is now complete.

05

Installation of outer slides

According to the mounting hole spacing diagram, mark the first point at 50.5mm from the drawer panel on the drawer bottom and mark the second point spaced 80mm apart.

Pre-installed drawer panel which is needed to measure the distance from the bottom of the drawer front to the bottom of the drawer box, which is 27.5mm in this case. The installation height of the outer rail equals the inner rail installation height plus this measured distance, i.e. 50 + 27.5 = 80.5mm.



Using a measuring tape, reference from the cabinet's structural bottom panel underside, to transfer the outer rail installation height, and mark this position on both left and right sides.

At the marked height on both left and right sides, draw a line that is the parallel to the cabinet bottom edge.

Following the mounting hole spacing diagram:

1. On the parallel reference line, mark the first point 35 mm from the edge.
2. Mark the second point 64 mm from the first point.
3. Mark the third point 64 mm from the second point.
4. Mark the fourth point 96 mm from the third point.

Note: Use the built-in handle type drawer panel extend at the mounting points inward by the thickness of the drawer panel.

Position the outer rail flush with the cabinet edge. Slide out the middle rail to expose the outer rail's mounting holes. Align these holes precisely with the pre-marked points.

Secure the outer rail by fastening self-tapping screws through its mounting holes, aligned with the pre-marked points. Use at least four self-tapping screws per outer rail side.

Finish the installation of outer slides.

06

Installation of drawer

Align the inner slide on both sides of the drawer with the slide channels of the middle rails mounted on the cabinet side panels. Push the drawer assembly firmly, inward until fully engaged.

The installation is finished.

Notes:

1. The soft-close ball bearing slide can be adjusted backward by the fixing screws of the slide with two. If multiple loads are installed, the upper layer can be installed with the top edge of the lower drawer panel as reference.