HIDOLD
Shawner 2.0 Narrow Tall Larder Units

Installation manual

Shawner 2.0
Narrow Tall Larder units
H1980mm

Pay Attention to Installation !

The depth of HIDOLD Narrow Tall Larder unit is 580mm, the recommended depth of cabinet is 600mm, and the minimum depth of cabinet is 560mm.

The width of HIDOLD Narrow Tall Larder unit is 300mm, the recommended width of cabinet is 300mm, and the minimum width of cabinet is 300mm.

Accessory list

There are 4 accessories in the accessory box of basket. Please follow the installation instruction to install the basket. Please check the accessories before installation.

Basket Guide Rail x 2

Basket Guide Rail Support x 2

Screws (M3 * 12mm) x 8

T-shaped Iron Tube (Hanger Integrated) x 2

STAGTE self-tapping screws TC STG T6 (M4 * 16mm) x 4

M5 Threaded Tube Expansion Screw x 4

Installation Hint Guide: ** Cut along dotted line to get the installation hint guide for integrated installation template.

Upper guide rail installation

The installation templates are separated along the dotted line. Please make sure you are divided only guide rail installation template for upper guide rail installation.

Measure the total width of the cabinet, and then mark the position of the screw hole for attaching the upper guide.

Fasten the front and the rear upper guide rail installation template to both end caps of the upper guide rail with the screws provided in the bag.

Install the upper guide rail assembly to the side wall and fasten with the screws.

Align the front edge of the upper guide rail installation template to the front edge of the cabinet side panel. Fasten the front and the rear upper guide rail to the side wall with the screws.

The upper guide rail is finished.

Installation of the lower guide rail

Measure the distance between the front and the rear screw holes of the lower guide rail. Mark the front and the rear screw holes on the bottom panel of the cabinet. Align it with the screw holes of the lower guide rail.

Drill the holes and install the screws.

Align the front and the rear screw holes of the lower guide rail with the screw holes on the bottom panel of the cabinet. Fasten the front and the rear lower guide rail to the bottom panel with the screws.

The installation of the lower guide rail is complete.

Main framework installation

Put the upper guide rail and the lower guide rail on the same level.

Put the main frame on the lower guide rail. Insert the main frame into the upper guide rail. Make sure the main frame is in the middle of the upper guide rail and the lower guide rail. Then push the main frame back.

Lock the main frame at the bottom of the lower guide rail.

Lift up the main frame with upper guide rail. Align the main frame with the screw holes with the two sides of the inner cabinet panel and fasten.

The main frame installation is complete.

Door panel installation

Measure the screw center of the top hinge and the bottom hinge on the door panel. Mark the screw holes on the door panel.

Pre-drill holes according to the installation template provided.

Fasten the hinges on the door panel with the screws provided.

Align the hinges with the screw holes on the side panel. Fasten the screws provided with the hinges. Make sure the door panel is parallel with the side panel.

Align the T-shaped bar with the main frame and fasten with the screws provided. Make sure the T-shaped bar is parallel with the main frame.

Door panel adjustment

Install the door panel and close the door.

Adjust the door panel to make sure the gap between all sides of the door panel and the cabinet is even and flush. Left-right adjustment: Adjust the left-right adjustment screw on the hinge to move the door panel left or right. Front-back adjustment: Adjust the front-back adjustment screw on the hinge to move the door panel front or back.

Adjust the tandem height of the door panel: Adjust the tandem height of the door panel to make sure the gap between the door panel and the cabinet is even and flush. Turn the tandem screw clockwise to raise the door panel. Turn the tandem screw counterclockwise to lower the door panel.

Adjust the gap between the upper and lower door panels: Loosen the screws on the upper and lower brackets. Move the upper and lower brackets to adjust the gap between the upper and lower door panels. Tighten the screws on the brackets.

Adjust the upper and lower gap of the door panel: Loosen the screws on the upper and lower brackets. Move the upper and lower brackets to adjust the gap between the door panel and the cabinet. Make sure the gap between the door panel and the cabinet is even and flush. Tighten the screws on the brackets.

After the door panel adjustment is completed, the installation is complete.

Attach the decorative panel to the door panel with the double-sided tape provided. Make sure the decorative panel is flush with the door panel.

Align the decorative panel with the main frame and fasten with the screws provided.

The decorative panel installation is complete.

The Installation of basket

Put the basket guide rail support on the guide rail. Adjust the height of the basket guide rail support to make sure the basket guide rail is level. Fasten the screws provided on the basket guide rail support.

Install the basket.

The installation of basket is complete.