

Recommend 3-Steps Series



- 1600 STEP 1 ADVANCED ABRASIVE COMPOUND**
+WOOL PAD REMOVE P1200 SANDING MARKS
+CUT FOAM PAD REMOVE P1500
- 2600 STEP 2 PROFESSIONAL DIAMOND CUT**
+ MEDIUM FOAM PAD REMOVE P2000 SANDING MARKS
- 3600 STEP 3 PREMIUM FINISH**
+ FINAL FOAM PAD REMOVE SWIRL & HOLOGRAM