

ENGLISH

WARNINGS

- Please read all instructions thoroughly and retain for future reference.
- Do NOT use this appliance if it is not working properly, or if it has been dropped or damaged.
- This appliance must only be supplied at safety extra low voltage corresponding to the marking on the appliance.

KNOW YOUR UNIT

PRODUCT

100

8 Coarse Disc Bit

9 Felted Wool Bit

Umbrella Top Bit

Barrel Bit

12 Cone Bit

- Electric Nail File
- 2 Jack Connector Socket
- 3 Controller
- 4 Jack Connector
- 5 Speed Controller
- 6 Dual-Direction / On / Off Switch
- Buai Birection 7 On 7 On Owiten
- 7 USB Connector

GETTING STARTED



Select the tool and firmly insert into the top of Electric Nail File.



Connect the Controller.
Plug the USB Connector into a USB power supply port.



Slide the Dual-Direction / On / Off Switch to turn



Adjust the speed using the Speed Controller.

AFTER USE

- 1. Switch the unit off and unplug from the USB power supply.
- 2. Pull Tool firmly to remove from the top of the Electric Nail File.

CARE AND MAINTENANCE

After each use clean the nail drill heads with soap and water, and sterilise by immersing in liquid disinfectant.

PRODUCT PARAMETER

	Product Model	RB-015E	Material	ABS
	Charging Voltage	DC5V	RPM	0~20000 rpm
	Max. Power	0.5W	Product Dimension	146*32*31mm
	Product G.W.	185g	Product N.W.	55g

108mm

108mm

108mm

108mm