NETUM C740 Pocket Barcode Scanner

Restore factory default Scanning the following barcodes one by one to restore the scanner to factory defaults.(Four steps included)



Step One



Step Two



Step Three



Step Four



View version number