

Leaf Thickness Gauge



Introduction:

The leaf thickness Gauge is mainly used to measure the leaf thickness of plants, so as to reflect the growth and nutritional status of plants through the measurement data.

Technical Parameters:

Model	LTG-1
Measuring Range	0~6mm
Resolution	0.01mm
Accuracy	0.015mm
Contact Area	Φ10 mm
Reader	Pointer
Net Weight	1kg