# KJ2004X1-BB1 Remote Interface Unit 2 (RIU2)

## Hazardous Atmosphere



II 3G Ex ec IIC Gc FM19ATEX0173U IECEx FMG 19.0019U FM21UKEX0017U



CL. 1 Zn 2 AEx/Ex ec IIC Gc FM17US0286U FM17CA0145U

#### **Power Specifications**

Local Bus Power +5 VDC at 500 mA

### **Environmental Specifications**

Ambient -40°C to +70°C Temperature

Shock 10g ½ Sinewave for 11msec

Vibration 1mm Peak to Peak from 2 to 13.2Hz;

0.7g from 13.2 to 150Hz

Airborne ISA-S71.04 –1985 Airborne Contaminants Class G3

Relative Humidity 5 to 95% Non-Condensing

**Note:** Refer to the product label for serial number and location and date of manufacture.

Warning: This product has specific instructions for installation, removal and operation in hazardous areas. Refer to document 12P2046 "DeltaV™ Scalable Process System Zone 2 Installation Instructions". Other installation instructions are available in the "DeltaV™ M-Series Hardware Installation and Reference" manual.

The communications network connected to the

DeltaV Remote Interface Unit must not be connected to a source that generates or contains under normal conditions a potential in excess of 60 VAC or 75 VDC.

#### Removal and Insertion

This unit cannot be removed or inserted with system power energized unless the area is known to be non-hazardous.

### Maintenance and Adjustment

This unit contains no user serviceable parts and should not be disassembled for any reason. Calibration is not required.

## Other Safety Approvals



