

Installation---Negative version


Confirm the place to install

Remove the original terminal

Choose the best position

Tighten the screws

Tighten the terminals



Fix the button

Plug the remoter

Blue light flash if install right

Tighten the power line

Tighten the Auto starter

