# **Product Specification**



**Product** 


Heliport Surface Mounted Perimeter Light

- 1 Technical Parameters
- 1.1 Dimensions (mm)



Tel: +86 133 1606 0761 website: www.spl-en.com

email: spl-en@foxmail.com



# 1.2 Technical Parameters

The following parameters are obtained under normal temperature test. (25°C)

Item of Test		Parameters
Model		SPL-020
Structure Parameter	Nominal Dimension	Ф104×150mm
	Installation Dimension	Pls see below.
	Material of Lamp Panel	Aluminum Die Casting
	Material of Cover	PC
Electrical Parameter	Rated Power	5W
	Input Voltage	AC 100-250V
	Light source	LED
	Light color	green
	Effective light intensity(cd)	≥5



# Address: Northeast 8 Road NO.22. Gusan Industrial Area Gu Zhen Town ,ZhongShan City. Guang Dong Province CHINA

Tel: +86 133 1606 0761 website: www.spl-en.com email: spl-en@foxmail.com


Operating mode	Operating mode	Steady burning
	Function	This product is vertically installed along touchdown and liftoff area edge, it can radiate steady burning green light at all direction in the night or low visibility daytime, to identify the borders of touchdown and liftoff area edge, enable pilots to land safely.
Other Parameter	Operating tem.	-40 ~ +55°C
	Wind load $^{ extstyle  e$	80m/s
	Protection	IP66
	Net Weight	0.88Kg

# 2. Characteristics of Lamp

- 1. Corrosion resistance, anti-ultraviolet.
- 2. International advanced cold light source, low power consumption, high brightness, the service life is up to 100000 hours.
- 3. The use of PC material, designed for impact resistance.
- 4. With lightning protection function.
- 5. This product is self-developed, with new product experiment;
- 6. The housing adopts integrated die-casting aluminium, with super performance of heat sinking and sealing;
- 7. The optical module of this product adopts reflex housing, high efficiency of light gathering, no extra scattered light pollution;

## 3. Installation

3.1 Schematic Diagram



## 3.2 Instruction

- a) Please read carefully the product specification before using the driver to make sure the operation environment can meet the requirement as per the specification.
- b) While connecting the tube to the power, please make sure the switch is "OFF".
- c) Do not disassemble the lamp by yourself.

## 4. Maintenance

- 4.1 keep every screw in tight
- 4.2 keep the light OFF when not using