# OSWELL

# **OSWELL E-GROUP LIMITED**

www.eoswell.com

## SH639-120A

#### 120A 3 PHASE LATCHING RELAY



#### **Contact Specifications:**

1. Contact Form: 3A(Release), 3B(Operate)

Default Form

- 2. Contact Material: AgSnO<sub>2</sub>
- 3. Contact Resistance:

 $\leq 2 \mathrm{m}\Omega (1\mathrm{A/6VDC})$ 

### Characteristics:

Characteristics:							
AMBIENT TEN	MP.	-40°C~+70°C					
VIBRATION RESISTANCE		10-55Hz,	0.5mm				
		(Double Amp	olitude)				
SHOCK RESISTANCE		98m/s <sup>2</sup> 11ms					
RELATIVE HU	MIDITY	45%~85%					
INSULATION	RESISTANCE	1000 M Ω (500VDC)					
DIELECTRIC STRENGTH	BETWEEN	2500 VAC	50/60Hz				
	CONTACTS	(1 minute)					
	BETWEEN	4000 VAC 50/60Hz					
	CONTACT &						
	COIL	(1 minute)					
	BETWEEN	6000 VAC	50/60Hz				
	CONTACTS	(1 mint					
	& CONTACT	(1 11111	ite)				
Creepage Distance		9mm					
Surge Voltage		6.0KV					
Contact Gap		$0.9\pm0.05$ mm					
Electrical Life		$\geq 1 \times 10^4 \text{OPS}$					
Mechanical Life		$\geq$ 5 x 10 <sup>5</sup> OPS					
PICK-UP TIME (At rated Voltage): $\leq$ 50ms							
RELEASE TIME (At rated Voltage): $\leq$ 50ms							
Bounce Time: ≤2ms							
Construction: DUST protected							
N.W. per unit: Approx. 250g							

#### Features:


Switching Current: 120A max Switching Voltage: 250VAC max Switching power: 30000VA max Dielectric Strength: 4kV/1min (between coil and contacts) RoHS Compliance, Dimensions (mm): 117×52×23

Coil Data (23°C):						
Rated	Pick-up	Pulse	COIL RESISTANCE X $(1\pm10\%) \Omega$			
Voltage	Voltage	Duration				
(VDC)	(VDC)	(ms) Min				
9	6.75	80	Single Coil Latching	32		
12	9	80		57		
24	18	80		230		
48	36	80		920		
9	6.75	80	Double Coil Latching	16		
12	9	80		29		
24	18	80		115		
48	36	80	Latening	460		
Coil Power Consumption: Single coil 2.5W						
Double Coil 5.0W						


#### **NOTICE:**

1. Relay is on the "release" or "operate" status when being released from stock, with the consideration of shock risen from transit an relay mounting, relay would be changed to "operate" or "release" status, therefore, when application (connecting the power supply),please reset the relay to "operate" or "release" status on request.

2. In order to maintain "operate" or "release" status, energized voltage to coil should reach the rated voltage, impulse width should be 5 times more than "operate" or "release" time. Do not energize voltage to "operate" coil and "release" coil simultaneously. And also long energized time (more than 1 min) should be avoided.



### Wiring Diagram:







# **OSWELL E-GROUP LIMITED**

www.eoswell.com


## **Outline Dimensions (mm):**





Single Coil





Double Coil